

M LEVEL D



Levelo

AEROLITE
Portable handbag Keyboard Case

SKU: LVLARLTBKCA16BK



Table of Contents

Product Overview	2
Specifications	2
Package Contents	3
Installation Guide	3
Case Storage Guide	4
LED Indicators	6
Power Options	6
Pairing Guide	7
Touch Pad Controls	8
Function Keys	8
Safety Instructions	9
FCC Statement	10
Disposal	11
Warranty	12
Contact Us	12

Product Overview

The LEVELO Aerolite Portable Handbag Keyboard Case is designed to offer a refined typing experience and a versatile, practical solution for productivity. This keyboard case is compatible with the iPad "10.9 10th Generation (2022) and iPad A11 "11 16th Generation (2025), providing easy portability with a sleek and durable design. It features scissor feet keys that ensure balanced typing precision, a remarkable battery life of up to 140 days, and an extended working time, making it ideal for long-term use. The built-in kickstand offers stable support, allowing you to use your device at an optimal angle for viewing or typing. In addition, the case provides splash resistance for added protection, making it a reliable and convenient accessory for your tablet.

Specifications

Battery Capacity	800mAh
Working Time	140 Days
Connection Distance	<10m
Charging Interface	Type-C
Standby Mode Current	0.51mA
Bluetooth Version	5.4

Charging Voltage	5V
Charging Time	2H
Product Material	TPU
Number Of Keys	78 Keys
Supported OS	iOS
Product Weight	650g

Package Contents

Bluetooth Keyboard x1
USB-C Charging Cable x1


Installation Guide

1. Place the case on a flat surface.
2. Align your device’s camera with the camera opening on the case.
3. Insert your device at an angle, starting from the top (camera side).
4. Let your device rest at the bottom of the case and gently press it down into place.
5. Press around all edges to ensure your device is properly installed within the case.
6. Unfold the keyboard cover and place it flat on a surface.




Case Storage Guide

1. Pull out the kickstand from the back of the case.




2. Fold the kickstand back towards the case.



3. Rotate the kickstand so it fits securely against the case.




4. Close the case, ensuring the kickstand is fully stored, and the case is compact.



LED Indicators

Keyboard Indicator	Indicator Color	Lighting Mode
Bluetooth Activation Indicator	White	The indicator stays lit for 5 seconds and turns off after that.
Bluetooth Pairing Indicator	White	The indicator keeps flashing and will turn off when the connection is established.
Charging Indicator	White	When the product is charging, red light stays on and will turn off when the battery is full.
Capslock Indicator	Red	Press Caps lock to switch to upper case letters. The light stays lit until the Caps lock is turned off.



Power Options

Ensure your keyboard is fully charged using a compatible USB-C 5V charger (not included) or via a USB-C port on a computing device.

1. To Power On:

Turn on the keyboard. The status indicator will blink for 5 seconds, then turn off.

2. To Power Off:

Turn off the keyboard. The keyboard will power down.

3. Standby Mode:

After 40 seconds of inactivity, the keyboard will enter Standby mode. Press any key to wake it up.

Pairing Guide

1. Ensure your device's Bluetooth connection is enabled.


2. Press and hold the Fn + C keys for 3 seconds. Release the keys once the LED on the Power key begins flashing rapidly. Your keyboard will enter pairing mode.

3. Open your device's Bluetooth settings and search for "AeroLite".

4. Select the appropriate keyboard from the list of available Bluetooth devices.

5. Your keyboard should now be paired and connected to your device.

6. If the pairing process fails, repeat the steps.



Bluetooth Pairing
LED Indicator



Touch Pad Controls

The Touch pad supports most common multi-touch gestures including:

- a. Swipe
- b. Tap
- c. Pinch
- d. Scroll

Function Keys



Homepage: Displays the main screen of the device.



LOCK: Activates the lock screen mode of the device.



Recent tasks: Displays the recent task view window of the device.



Search: Opens the device's global search function.



Input method switch: Switches between keyboard languages (device must be in active mode).



Microphone: Activates Siri.



Previous track: Return to the previous track in the selected playlist.



Pause/Play: Starts or pauses the current playlist.



Next song: Skip to the next track in the selected playlist.



Mute: Mutes the audio of the device.



Lower volume: Lowers the volume of the device.



Increase volume: Raise the volume of the device.



Bluetooth: Pairs and connects with your device via Bluetooth.



Brightness decrease: Decreases the screen brightness.



Brightness increase: Increases the screen brightness.

Safety Instructions

1. If you need to use the keyboard frequently, or if you do not need the keyboard for a while, please avoid folding or pressing the keyboard. Doing so may cause damage and drain the keyboard's battery, affecting its performance during future use.
2. When the keyboard is not in use, it will enter sleep mode after 20 minutes of inactivity and can be awakened by pressing any key.
3. Keep the keyboard away from sharp objects and open flames.
4. Avoid pressing the keyboard with heavy objects for extended periods.
5. Do not place the keyboard near sources of heat.
6. The keyboard contains a lithium battery. Please do not dispose of it directly.

7. The keyboard is designed for use in environments with temperatures ranging from -10°C to 45°C. Do not use the keyboard in extreme hot or cold conditions.
8. Keep the keyboard away from oil or other organic solvents.
9. Do not use the keyboard in a damp environment for extended periods.
10. It is not recommended to use the keyboard in aerospace facilities or areas with high levels of signal interference.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference; and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for assistance.

RF warning statement:

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products procured directly from the **Levelo** website or physical store comes with a 24-month warranty. **Levelo** products purchased from any of our authorized dealers are guaranteed with a one-year warranty. If you wish to extend this warranty, you'll need to go to our website at **<https://www.levelobrand.com/warranty>** and fill out the necessary form, making sure to include your personal information and a photo of the product. After your request has been evaluated and accepted, we'll send you an email notification to affirm the extension of your product's warranty.

For more info, please check:

<https://www.levelobrand.com/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **Info@levelobrand.com**

Website: **<https://www.levelobrand.com/>**

Email: **Info@levelobrand.com**

Instagram: **levelobrand**

Facebook: **levelobrand**