

M LEVELD



Levelo

**Montego
10000mAh Power Bank**

SKU: LVLMTGOPB10K

Table of Contents

Product Overview	2
Specifications	2
Product Features	2
Instructions for Use	3
Charging Guidelines	4
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Montego 10000mAh Power Bank offers a compact and efficient charging solution for various devices. It features a Type-C grip cable for easy handling and fast charging. The built-in LED display shows the battery status, while the Type-C input/output port ensures compatibility with multiple devices. With intelligent power output, it provides controlled, fast charging for modern devices, making it a reliable and portable option for everyday use.

Specifications

Battery Capacity	10000mAh / 38.5Wh
Type-C Input	5V/2.4A, 9V/2A, 12V/1.5A
Type-C Output	5V/2.4A 9V/2.22A 12V/1.67A
Product Size	33 x 49.5 x 88.5mm
Product Weight	170g
Grip Cable Length	17.7cm

Product Features

1. Type-C Grip Cable

The power bank is equipped with a Type-C grip cable, which offers a

secure and comfortable handling experience. This cable ensures reliable connections for quick and safe charging of your devices.

2. Fast Charging

This power bank supports fast charging technology, providing a quicker and more efficient charging process for your devices, so you can get back to using them sooner.

3. LED Display for Battery Status

The built-in LED display shows the current battery level of the power bank. This allows users to easily monitor the remaining charge and plan when to recharge the power bank.

4. Compact and Portable Design

Designed with portability in mind, this power bank is lightweight and compact, making it easy to carry in a bag or pocket. It offers convenience for people who are always on the go.

5. Intelligent Power Output

The power bank is equipped with intelligent power output, which ensures that the correct amount of power is delivered to your device. This feature helps prevent overcharging and optimizes the charging efficiency for a variety of devices.

Instructions for Use

1. Before using the power bank, ensure it is compatible with your device by checking the required voltage and amperage. The output voltage of the power bank must match the specifications of your device to prevent damage.

2. Always use the supplied cable to connect your device to the power bank's output port.

3. Make sure the power bank is turned on before connecting your device.

4. Once your device is fully charged, disconnect it from the power bank to avoid unnecessary power usage.

Charging Guidelines

1. Connect one end of the USB cable to the input port of the power bank.
2. Connect the other end of the USB cable to a power source such as a wall charger, computer, or any compatible power outlet.
3. The charging progress will be displayed on the LED screen of the power bank.
4. Once the power bank reaches a full charge, disconnect it from the power supply to avoid overcharging and preserve battery life.

Safety Precautions

1. Avoid leaving the power bank in high-temperature areas or near heat sources to prevent overheating and potential damage to the cells.
2. The device is not waterproof. Do not expose it to water or use it in rainy conditions. Keep it away from liquids.
3. Store the power bank in a cool, dry location. Do not leave it in a hot environment, such as inside a car.
4. Only use the original certified cables and power supplies to ensure safe and proper functioning. Using substitutes may damage the device.
5. Avoid overcharging the device. Disconnect it from the charger once it reaches full charge to prevent damage.
6. Do not use the power bank if it shows any signs of damage, such as cracks or other visible issues.
7. Do not expose the power bank to fire to reduce the risk of explosion.
8. Do not throw the power bank. Mishandling may cause damage or malfunction.

9. Do not leave the power bank unused for long periods of time. Ensure it is used at least once every six months to prevent battery depletion.
10. Do not attempt to open the device, as there is a risk of electric shock.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products procured directly from the **Levelo** website or physical store comes with a 24-month warranty. **Levelo** products purchased from any of our authorized dealers are guaranteed with a one-year warranty. If you wish to extend this warranty, you'll need to go to our website at <https://www.levelobrand.com/warranty> and fill out the necessary form, making sure to include your personal information and a photo of the product. After your request has been evaluated and accepted, we'll send you an email notification to affirm the extension of your product's warranty.

For more info, please check:

<https://www.levelobrand.com/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at: Info@levelobrand.com

Website: <https://www.levelobrand.com/>

Email: Info@levelobrand.com

Instagram: [levelobrand](#)

Facebook: [levelobrand](#)