

LEVELO



Levelo

**SOUNDMASTER Hybrid ANC
Headphone with Smart Touch Panel**

SKU: LVL-SNDMSTR-HP-DGY

Table of Contents

Specifications	2
Function Description	2
ANC Function Description	2
Schematic View	3
Bluetooth Pairing	3
Connecting with the AUX Cable	4
Smart Touch Operation Guide	4
Button Guide	5
LED Light Status	5
Important Notes	5
Disposal	6
Warranty	6
Contact Us	6

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Specifications

Chipset	Bluetrum
Battery Capacity	200mAh
Frequency	2.4 to 2.48354GHz
Transmission Distance	10 m
Charging Time	1.5 to 2 Hours
Input Voltage	DC 5V
Standby Time	300 Hours
Playtime ANC ON/OFF (100 % Volume)	8 Hours (ANC ON) / 12 Hours (ANC OFF)
Impedance	32Ω
Sensitivity	108dB+/-3dB

Function Description

To power the device on or off, press and hold the power button() for about 3 seconds. You will hear a prompt indicating whether the headphones are turned on or off.

ANC Function Description

1. When Bluetooth is ON, short press the ANC button() to switch to "Transparent Mode". Press again to activate Active Noise Cancellation (ANC), and press once more to turn ANC off.

2. When Bluetooth is OFF, press and hold the ANC button for about 2 seconds to enter "Transparent Mode". Press and hold again for another 2 seconds to activate Active Noise Cancellation.
3. Press and hold the ANC button again for about 2 seconds to turn off Active Noise Cancellation (ANC).


Bluetooth Pairing

1. Power on the headphones. You will hear a tone, and the LED indicator will flash blue and red.
2. Enable Bluetooth on your mobile device and search for available devices. Select "SoundMaster" from the list.
3. Once successfully paired, you'll hear another tone, and the LED indicator will flash blue intermittently.
4. In Bluetooth mode, playback and volume can be adjusted using the on-ear controls or directly from your paired device.

Connecting with the AUX Cable

Plug one end of the included 3.5mm auxiliary cable into the AUX input port located at the bottom of the right earcup to enter AUX mode. Connect the other end to the audio output port of your media device. In auxiliary mode, playback and volume can be adjusted using the controls on your connected device.

Schematic View



- 1. Microphone
- 2. LED Indicator
- 3.5 .3mm AUX Port
- 4. USB Type-C Charging Port
- 5. Power On/Off Button
- 6. ANC On/Off Button

Smart Touch Operation Guide

- 1. Double Press: Play/Pause music or Answer/End calls.
- 2. Grip and Hold: Pause playback; Release to resume playback.
- 3. Swipe Left/Right: Previous track / Next track.
- 4. Swipe Up/Down: Volume up / Volume down.



Button Guide

To increase or decrease the volume, long press the($\oplus$)or($\ominus$)button. To switch tracks, short press the($\oplus$)button for the next track or the ($\ominus$)button for the previous track.

LED Light Status

- 1. Charging:** A steady bright red light indicates charging. When fully charged, the red light turns blue.
- 2. Power On:** The LED flashes blue, then alternates between red and blue.
- 3. Pairing:** The red and blue LEDs flash alternately during pairing mode.
- 4. Connected:** A blue light flashes every 4 seconds when connected.
- 5. Playback:** The LED flashes blue intermittently during playback.

LED Light Status

- 1.** You will hear an indication tone when the battery is low.
- 2.** Keep the product away from small children.
- 3.** Protect the product from impacts.
- 4.** Do not immerse the product in water.
- 5.** Use the product within normal ambient temperatures and avoid excessively humid environments.
- 6.** Always verify charging specifications before connecting the product to charge.
- 7.** Avoid listening at high volume for extended periods, as it may damage your hearing.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products procured directly from the **Levelo** website or physical store comes with a 24-month warranty. **Levelo** products purchased from any of our authorized dealers are guaranteed with a one-year warranty. If you wish to extend this warranty, you'll need to go to our website at **<https://www.levelobrand.com/warranty>** and fill out the necessary form, making sure to include your personal information and a photo of the product. After your request has been evaluated and accepted, we'll send you an email notification to affirm the extension of your product's warranty.

For more info, please check:

<https://www.levelobrand.com/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **Info@levelobrand.com**

Website: **<https://www.levelobrand.com/>**

Email: **Info@levelobrand.com**

Instagram: **levelobrand**

Facebook: **levelobrand**