

**LEVEL**



**Levelo**

**LOCKVAULT Digital 128GB  
Encrypted USB Flash Drive**


SKU: LVLLCKVLTGY



# Table of Contents

Product Overview	2
Indicator Guide	2
Specifications	3
Instructions for Use	3
Function Guide	4
Notice	4
Disposal	5
Warranty	6
Contact Us	6

# Product Overview



## Indicator Guide

Status	Indicator
Red Light	PIN Approved
Solid Red Light	Re-enter PIN
Blue Light	Unlocked
Solid Blue Light	Connecting to PC
Red and Blue Light Flashing	Valid Input

## Specifications

Connector Type	USB-A 3.1 Gen 1
Capacity	128GB
Read/Write Speed	Read: Approx 160MB/s, Write: Approx 120MB/s
Supported Operating System	Windows 7/8/10/11, MacOS, Linux, Android OS
Encryption Method	AES256
Timed Auto-Lock	Inactivity Of 30 Seconds
Operating Temperature	0° ~70°C
Material	Zinc Alloy + ABS
Product Size	11.5 x 26 x 80mm

## Instructions for Use

### A. Initial PIN

**Default PIN:** 1122334

### B. Usage Guide

1. Press and hold the power button for 3 seconds. The red LED will turn on.
2. Enter the PIN. The red and blue LEDs will blink once to indicate each valid input.
3. Press the key button to unlock. The blue LED will turn on.
4. Connect the flash drive to your PC, and it will be recognized automatically.
5. Disconnect the flash drive to initiate encryption.

**Note:** The flash drive can be unlocked after being connected by following the same steps.

## C. Changing PIN

1. Unlock the flash drive. The blue LED will turn on.
2. Press the key button. The red and blue LEDs will blink once.
3. Enter a new PIN with 6 to 15 numeric digits. Avoid using sequential digits like 123456 or repeating digits like 888888.
4. Press the key button to confirm. The red and blue LEDs will blink once.
5. Re-enter the new PIN and press the key button again to confirm. The red LED will light up for 3 seconds, then the blue LED will turn on.

## Function Guide

1. The flash drive will automatically lock after 30 seconds if it is not connected.
2. If you enter the incorrect PIN 7 times consecutively: The red and blue LEDs will blink.
3. If you enter the incorrect PIN 10 times consecutively: The flash drive will reset to its factory settings. All data will be erased. The PIN will be reset to the default PIN (1122334).
4. To reactivate the flash drive:
  - 4.1 Press the power button for 3 seconds.
  - 4.2 Unlock it using the default PIN.
  - 4.3 Connect it to the PC.
  - 4.4 Format the flash drive.

## Notice

1. It's important to store your PIN in a safe place. If the PIN is lost or forgotten, access to the drive will not be possible.
2. A factory reset will erase all data completely.

3. The device comes pre-formatted with FAT32.
4. To copy large files (such as those over 4GB), please reformat the drive to exFAT.
5. The device has a standby power consumption.
6. The built-in lithium-ion polymer battery may drain if stored for long periods without use.
7. If there is no LED indication, connect the device to a PC to recharge.
8. Recharging may take up to 2 hours.
9. When setting your PIN, choose between 6 and 15 digits. Avoid using sequential digits like "123456" or repeating digits such as "888888."
10. You are responsible for the security and backup of your data at all times. The manufacturer is not liable for any data loss.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products procured directly from the **Levelo** website or physical store comes with a 24-month warranty. **Levelo** products purchased from any of our authorized dealers are guaranteed with a one-year warranty. If you wish to extend this warranty, you'll need to go to our website at **<https://www.levelobrand.com/warranty>** and fill out the necessary form, making sure to include your personal information and a photo of the product. After your request has been evaluated and accepted, we'll send you an email notification to affirm the extension of your product's warranty.

For more info, please check:

**<https://www.levelobrand.com/warranty>**

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at: **[Info@levelobrand.com](mailto:Info@levelobrand.com)**

Website: **<https://www.levelobrand.com/>**

Email: **[Info@levelobrand.com](mailto:Info@levelobrand.com)**

Instagram: **levelobrand**

Facebook: **levelobrand**