

LEVEL



Levelo


**TOWERHAZE Ultrasonic Indoor
Aroma Diffuser**

SKU: LVL-TWRHZE-DIFF-BK

Table of Contents

Product Overview	2
Safety Precautions	2
Replacing the Nozzle	3
Function Introduction	3
Specifications	5
Package Contents	5
Instructions for Use	5
Indicator Light and Button Guide	6
Remote Controller Overview	8
Using the Remote Controller	8
App Instructions	9
Troubleshooting Methods	14
Maintenance Guide	15
Disposal	15
Warranty	16
Contact Us	16

Product Overview




Safety Precautions

1. Always position the diffuser upright for optimal performance.
2. Avoid tilting the diffuser, as this may cause oil to spill inside and damage the device.
3. Use only the original power cord provided with the diffuser. Ensure the power cord is positioned to prevent any tripping hazards.
4. Keep the diffuser out of reach of children.
5. Avoid impacts or dropping the diffuser, as this may cause damage to the device.
6. Do not stand too close to the mist while the diffuser is in operation.


Replacing the Nozzle

1. Unplug the diffuser and remove the fragrance oil bottle. Gently pull out the small tube. Using tweezers, carefully wiggle and remove the black nozzle.



2. Insert the new nozzle, ensuring it is securely pressed into the top of the diffuser. Reattach the tube to the nozzle.


Note: Ensure the tube is inserted correctly within the nozzle to ensure proper diffusion of scent. The nozzle includes a small round tube holder where the tube must be firmly placed. Tip: If you have trouble locating the tube holder, use a flashlight to enhance visibility inside the nozzle.



Function Introduction

The scent diffuser is designed with the latest cold-air diffusion technology, which transforms any of the hotel-inspired fragrance oils into a dry nano mist. This allows the scent to remain suspended in the air for an extended period, providing superior, long-lasting coverage.

Water and heat are not used, ensuring that the therapeutic properties of the fragrance oils are preserved without altering their scent. Advanced atomization technology is utilized, making the diffuser residue-free and ensuring its safety for pets, children, artwork, and furniture. The model is equipped with an easy-to-use remote control for convenience. Please ensure that you follow the instructions outlined in this manual to use the device correctly.




Specifications

Battery Capacity	3600mAh
Input	5V/2A
Power Output	10W
Timer Setting	1H, 4H, 8H
Working Time	Low Intensity: 12H, Medium Intensity: 10H, High Intensity: 8H
Storage Capacity	120ml
Product Weight	1100g
Product Size	88.5 x 88.5 x296mm
Material	Aluminum + Plastic

Package Contents


The package contains the diffuser with an empty 120mL bottle, remote controller, USB cable, adapter, metal hook, spare nozzle, seal rubber ring, and user manual. The remote controller is designed for the convenient adjustment of fragrance concentration levels to suit your preferences, as well as for setting the desired operating duration of the device.

Instructions for Use




Step 1: Remove the Empty Bottle

- 1.1 Remove the upper part of the diffuser directly.
- 1.2 Rotate the bottle counter-clockwise to detach it.



Step 2: Add the Fragrance Oil

Fill the bottle with your preferred fragrance oil.



Step 3: Install the Bottle and Upper Part

Place the upper part back into the diffuser securely.



Step 4: Power On the Diffuser

4.1 Connect the device using the USB-C cable and adapter.

4.2 Use the remote controller to power on the device, or press the power button to turn it on.

Note: By default, the diffuser will emit scent for 30 seconds, then pause for 180 seconds. This cycle will continue for 8 hours, after which the device will turn off automatically.


Indicator Light and Button Guide


The power button located on the front of the device functions both as the power button and as the control for misting and timer settings once the device is powered on.



1. To turn the device on, simply press the power button. The device will emit fragrance for 30 seconds, followed by a 180-second pause. This cycle will continue for 8 hours, after which the device will automatically turn off.

2. Power / Liquid Indicator

For the rechargeable diffuser, the power indicator () will be fully lit when the device is turned on.



3. Misting Control

3.1 After the device is turned on, press the power button once to adjust the mist settings:

3.2 When the device is on, the mist setting is LOW, releasing scent for 30 seconds, followed by a 180-second pause.

3.3 Press once: The mist setting is MED, releasing scent for 30 seconds, followed by a 120-second pause.

3.4 Press once again: The mist setting is HIGH, releasing scent for 30 seconds, followed by a 60-second pause.

4. Timer Settings

4.1 After the device is turned on, press the power button twice to adjust the timer setting. This feature allows the device to cycle through misting at your preferred duration, automatically powering off when the time is up:

4.2 Press twice: 1-hour timer. The screen on the front of the device will display 1H. The device will turn off automatically after 1 hour.

4.3 Press twice again: 4-hour timer. The screen on the front of the device

will display 4H. The device will turn off automatically after 4 hours.

4.4 Press twice again: 8-hour timer. The screen on the front of the device will display 8H. The device will turn off automatically after 8 hours.

Remote Controller Overview



Using the Remote Controller

- ON:** Press to turn the device on.
- OFF:** Press to turn the device off.
- LOW:** The diffuser will mist scent for 30 seconds, followed by a 180-second pause.
- MED:** The diffuser will mist scent for 30 seconds, followed by a 120-second pause.
- HIGH:** The diffuser will mist scent for 30 seconds, followed by a 60-second pause.
- 1H:** 1-hour timer setting. The screen on the front of the device will display 1H, and the device will turn off automatically after 1 hour.



4H: 4-hour timer setting. The screen on the front of the device will display 4H, and the device will turn off automatically after 4 hours.



8H: 8-hour timer setting. The screen on the front of the device will display 8H, and the device will turn off automatically after 8 hours.

App Instructions

This product is compatible with the Smart Life app, allowing you to control the diffuser remotely. To get started, download and install the Smart Life app on your device. You can either scan the QR code below or search for "Smart Life" in the Google Play Store or the App Store to find the app.




1. Open the app and select the device.


Note: Before turning on the diffuser, long press the button until the Wi-Fi indicator flashes on the LED display.



2. Input the Wi-Fi password that your phone is connected to.



3. Once connected, the status will show as Succeeded.



4. Enter the Home page of the app.



5. App Control Interface



1-Turn On/Off: To turn the diffuser on or off, tap the ON/OFF button at the bottom of the app screen.




2-Misting Mode: Select the misting mode (Low, Medium, High) by tapping the corresponding button.



3-Timer: Set the timer for 1 hour, 4 hours, or 8 hours by selecting the appropriate timer option.



4-Add Schedule: To set a schedule, tap the Add Schedule button. You can customize the schedule by setting the Repeat, Mode, Countdown, and other preferences.



Troubleshooting Methods

Problem	Solution
No Misting	<ol style="list-style-type: none">1. Check the power supply.2. Inspect the misting outlet hole to ensure the device is pumping air.3. Ensure that the top part of the diffuser is correctly installed.4. Ensure that the bottle is securely tightened into the diffuser head.

Maintenance Guide

To ensure optimal performance, the scent diffuser should be cleaned every 1-2 months. Follow these steps to clean the inner workings of the device:

1. Remove the upper part of the diffuser and fill the bottle with rubbing alcohol.
2. Reattach the upper part with the bottle to the diffuser.
3. Turn on the diffuser and let it run for 15 minutes to ensure the alcohol circulates through the device.
4. Remove the electric cord from the diffuser and position the device upright. Wipe the device with a damp cloth to remove oil stains and fingerprints. Do not use any harsh or abrasive materials to clean the device.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products procured directly from the **Levelo** website or physical store comes with a 24-month warranty. **Levelo** products purchased from any of our authorized dealers are guaranteed with a one-year warranty. If you wish to extend this warranty, you'll need to go to our website at **<https://www.levelobrand.com/warranty>** and fill out the necessary form, making sure to include your personal information and a photo of the product. After your request has been evaluated and accepted, we'll send you an email notification to affirm the extension of your product's warranty.

For more info, please check:

<https://www.levelobrand.com/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **Info@levelobrand.com**

Website: **<https://www.levelobrand.com/>**

Email: **Info@levelobrand.com**

Instagram: **levelobrand**

Facebook: **levelobrand**